





Automated Temperature Monitoring | Recording | Alerting














Sensor thermometer pictured

Cut operating costs | Improve customer experience | Become more efficient

5550

Place sensor in air vent or directly in cooled air supply

Simple Deployment



2. Place a sensor in the home to view ambient temperature



3. Visualize all temperature data to predict failure

